

# ORS Assembly Checklist (Version 2026/02/23)

ORS Number: \_\_\_\_\_

Person: \_\_\_\_\_

Date: \_\_\_\_\_

Please check each item one after the another in this order, then scan or take a picture of checklist once it is filled.

## Before closing the ORS

- Check power cable is plugged to the "PWR\_PC" port on PCB
- Check red and black wires are in the right order
- Pull on both ends of power cable to check it is firmly attached
- Pull on both ends of ethernet data cable to check it is firmly attached
- Pull on LED power cable to check it is firmly attached
- Write down PCB and PC serial numbers
- Check and count that all 17 PCB (SDR board) screws are not loose
- Take a picture of the open ORS

## Before screwing the enclosure

- Check there is no gap between top and bottom enclosure to make sure the red waterproof seal is placed correctly and there are no cables sticking out

## ORS check after closing it

- Check all screws are on the enclosure
- Check ORS has all its label on (ORS name + ORS model + "*do not plug...*" label)